



YFM350S

3GD-AE7

SUPPLEMENTARY SERVICE MANUAL

FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and data for the YFM350S. For complete service information procedures it is necessary to use this Supplementary Service Manual together with the following manual.

YFM350X(J) '97 SERVICE MANUAL: 3GD-AE5
YFM350X(P) 2002 SUPPLEMENTARY SERVICE MANUAL: 3GD-AE6

YFM350S
SUPPLEMENTARY
SERVICE MANUAL
©2004 by Yamaha Motor Co., Ltd.
First edition, January 2004
All rights reserved.
Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

**WARNING**

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander or a person checking or repairing the machine.

CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the machine.

NOTE:

A **NOTE** provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “symbols”)

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.

2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

② ①

REAR WHEELS AND REAR AXLE HUB CHAS

CHASSIS

REAR WHEELS AND REAR AXLE HUB

④

⑤

⑥

⑦

| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Removing the rear wheels and rear axle hub | | Remove the parts in the order listed. |
| 1 | Cotter pin | 2 | Refer to "REAR WHEEL AND WHEEL HUB" in chapter 6. |
| 2 | Axle nut | 2 | (Manual No.: 3GD-AE5) |
| 3 | Rear wheel | 2 | |
| 4 | Wheel hub | 2 | |
| 5 | Bolt | 2 | |
| 6 | Nut | 1 | Refer to "REMOVING THE REAR AXLE" and "INSTALLING THE REAR AXLE". |
| 7 | Locknut | 2 | |
| 8 | Adjusting bolt | 2 | |
| 9 | Brake caliper | 1 | |

NOTE:
Do not apply the brake pedal and do not use the parking brake when the brake caliper is off of the brake disc as the brake pad will be force shut.

REAR WHEELS AND REAR AXLE HUB CHAS

8. Remove:
• rear axle ①

CAUTION:
• Never directly tap the axle end with a hammer, since this will result in damage to the axle thread and spline.
• Attach a suitable socket ② on the axle end and tap it with a soft hammer, then pull out the rear axle to the right.

EBS00007

INSTALLING THE REAR AXLE ← ③

1. Install:
• nut ①
• bolts ②

a. Tighten the nut with rear axle nut wrench (48 mm) ③ to specification while holding the rear axle.
























Axle nut wrench (48 mm)
P/N. 90890-01498/YM-37134

Nut
180 Nm (16.0 m · kg, 115 ft · lb)
LOCTITE®

b. Tighten bolts ②.

Bolt
7 Nm (0.7 m · kg, 5.1 ft · lb)
LOCTITE®

← ⑧

| | | | |
|--|---|---|---|
| ① GEN INFO  | ② SPEC  | | |
| ③ CHK ADJ  | ④ ENG  | | |
| ⑤ CARB  | ⑥ CHAS  | | |
| ⑦ ELEC  | ⑧ TRBL SHTG ? | | |
| ⑨  | ⑩  | | |
| ⑪  | ⑫  | | |
| ⑬  | ⑭  | | |
| ⑮  | | | |
| ⑯  | ⑰  | ⑱  | |
| ⑲  | ⑳  | ㉑  | ㉒  |
| ㉓  | ㉔  | | |

EB003000

ILLUSTRATED SYMBOLS

Illustrated symbols ① to ⑧ are printed on the top right of each page and indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Troubleshooting

Illustrated symbols ⑨ to ⑮ are used to identify the specifications appearing in the text.

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Special tool
- ⑫ Torque
- ⑬ Wear limit, clearance
- ⑭ Engine speed
- ⑮ Ω, V, A

Illustrated symbols ⑯ to ㉒ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑯ Apply engine oil
- ⑰ Apply gear oil
- ⑱ Apply molybdenum disulfide oil
- ⑲ Apply wheel bearing grease
- ⑳ Apply lightweight lithium soap base grease
- ㉑ Apply molybdenum disulfide grease
- ㉒ Apply silicon grease

Illustrated symbols ㉓ to ㉔ in the exploded diagrams indicate where to apply a locking agent ㉓ and when to install a new part ㉔.


- ㉓ Apply the locking agent (LOCTITE®)
- ㉔ Replace

CONTENTS

| | |
|---|----|
| GENERAL INFORMATION | 1 |
| MACHINE IDENTIFICATION | 1 |
| MODEL LABEL | 1 |
| SPECIAL TOOLS | 2 |
| | |
| SPECIFICATIONS | 3 |
| GENERAL SPECIFICATIONS | 3 |
| MAINTENANCE SPECIFICATIONS | 5 |
| ENGINE | 5 |
| CHASSIS | 7 |
| ELECTRICAL | 10 |
| CABLE ROUTING | 11 |
| | |
| PERIODIC CHECKS AND ADJUSTMENTS | 23 |
| INTRODUCTION | 23 |
| PERIODIC MAINTENANCE/LUBRICATION | 23 |
| SEAT, FENDERS AND FUEL TANK | 25 |
| SEAT, SIDE COVERS, AND FRONT PANEL | 25 |
| FOOT PROTECTORS, ENGINE SKID PLATE, AND FRONT BUMPER | 26 |
| HEADLIGHTS AND FRONT FENDER | 27 |
| REAR FENDER | 28 |
| FUEL TANK | 30 |
| CHASSIS | 32 |
| CHECKING THE FRONT BRAKE PADS | 32 |
| ADJUSTING THE PARKING BRAKE | 32 |
| ADJUSTING THE REAR SHOCK ABSORBER | 33 |
| ELECTRICAL SYSTEM | 35 |
| CHECKING AND CHARGING THE BATTERY | 35 |
| ADJUSTING THE HEADLIGHT BEAMS | 40 |
| REPLACING A HEADLIGHT BULB | 41 |
| | |
| ENGINE | 42 |
| ENGINE REMOVAL | 42 |
| INSTALLING THE ENGINE | 42 |
| CLUTCH | 43 |
| INSTALLING THE RIGHT CRANKCASE COVER | 43 |
| | |
| CARBURETOR | 44 |
| CARBURETOR | 44 |

| | |
|--|----|
| CHASSIS | 47 |
| REAR WHEELS AND REAR AXLE HUB | 47 |
| REMOVING THE REAR AXLE | 49 |
| INSTALLING THE REAR AXLE | 50 |
| FRONT ARMS AND FRONT SHOCK ABSORBER | 51 |
| REAR BRAKE | 53 |
| ASSEMBLING THE REAR BRAKE CALIPER | 53 |
| REAR SHOCK ABSORBER AND SWINGARM | 54 |
| HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER | 56 |
| DISPOSING OF THE REAR SHOCK ABSORBER AND GAS CYLINDER | 56 |
| | |
| ELECTRICAL | 57 |
| ELECTRICAL COMPONENTS | 57 |

YFM350S WIRING DIAGRAM



GENERAL INFORMATION
MACHINE IDENTIFICATION

MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.

EB102001

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.




When placing an order, refer to the list provided below to avoid any mistakes.

For US and CDN

P/N. YM-, YU-, YS-, YK-, ACC-

Except for US and CDN

P/N. 90890-

| Tool No. | Tool name/How to use | Illustration | |
|-------------------------|---|---|--|
| 90890-01443 YU-33975 | Steering nut wrench This tool is needed to loosen and tighten the rear shock absorber locknut. |  | |
| 90890-01498 YM-37134 | Axle nut wrench (46 mm) This tool is needed to loosen or tighten the rear axle nut. |  |  |



SPECIFICATIONS

GENERAL SPECIFICATIONS

| Model | YFM350S |
|-------------------------------|--|
| Model code number | 5YT1 (For USA and Oceania) 5YT2 (For CDN) 5YT3 (For Europe) |
| Dimensions | |
| Overall length | 1,770 mm (69.7 in) |
| Overall width | 1,095 mm (43.1 in) |
| Overall height | 1,080 mm (42.5 in) |
| Seat height | 820 mm (32.3 in) |
| Wheelbase | 1,210 mm (47.6 in) |
| Minimum ground clearance | 115 mm (4.53 in) |
| Basic weight | |
| With oil and full fuel tank | 180.0 kg (397 lb) |
| Minimum turning radius | 3,100 mm (122 in) |
| Engine | |
| Engine type | Air-cooled 4-stroke, SOHC |
| Cylinder arrangement | Forward-inclined single cylinder |
| Displacement | 349.0 cm ³ (21.30 cu.in) |
| Bore × stroke | 83.0 × 64.5 mm (3.27 × 2.54 in) |
| Compression ratio | 9.20 : 1 |
| Compression pressure | 850 kPa (8.5 kg/cm ² , 120.9 psi) at 350 r/min |
| Starting system | Electric starter |
| Oil capacity | |
| Engine oil | |
| Periodic oil change | 2.50 L (2.20 Imp qt, 2.64 US qt) |
| With oil filter replacement | 2.60 L (2.29 Imp qt, 2.75 US qt) |
| Total amount | 3.20 L (2.82 Imp qt, 3.38 US qt) |
| Fuel | |
| Type | Regular unleaded gasoline only (For CDN and Europe) Unleaded gasoline only (For USA and Oceania) |
| Tank capacity | 9.0 L (1.98 Imp gal, 2.38 US gal) |
| Reserve amount | 2.7 L (0.59 Imp gal, 0.71 US gal) |
| Carburetor | |
| Type/manufacturer | BSR36/MIKUNI |

GENERAL SPECIFICATIONS

SPEC



| Model | YFM350S |
|--------------------------------|---|
| Transmission | |
| Primary reduction system | Spur gear |
| Primary reduction ratio | 76/24 (3.167) |
| Secondary reduction system | Chain drive |
| Secondary reduction ratio | 38/13 (2.923) |
| Transmission type | Constant mesh, 6-speed forward, 1-speed reverse |
| Operation | Left foot operation |
| Gear ratio | |
| 1st | 36/16 × 20/27 × 29/18 (2.685) |
| 2nd | 33/20 × 20/27 × 29/18 (1.969) |
| 3rd | 29/23 × 20/27 × 29/18 (1.504) |
| 4th | 27/26 × 20/27 × 29/18 (1.239) |
| 5th | 25/28 × 20/27 × 29/18 (1.066) |
| 6th | 23/29 × 20/27 × 29/18 (0.946) |
| Reverse | 33/16 × 33/10 (6.806) |
| Chassis | |
| Frame type | Steel tube frame |
| Caster angle | 6° |
| Trail | 26.0 mm (1.02 in) |
| Toe-in (unloaded) | 20 ~ 30 mm (0.79 ~ 1.18 in) |
| Tires | |
| Type | Tubeless |
| Size | |
| front | AT21 × 7-10 |
| rear | AT20 × 10-9 |
| Manufacturer | |
| front | DUNLOP |
| rear | DUNLOP |
| Type | |
| front | KT851B |
| rear | KT877A |
| Brakes | |
| Front brake | type |
| | operation |
| Rear brake | type |
| | operation |
| | Dual disc brake |
| | Right hand operation |
| | Single disc brake |
| | Right foot operation |
| Electrical | |
| Ignition system | DC C.D.I. |
| Generator system | A.C. magneto |
| Battery voltage/capacity | 12 V/8.6 Ah |
| Battery type | YTZ10S |
| Bulb wattage × quantity | |
| Headlight | 12 V 30 W/30 W × 2 |
| Tail/brake light | 12 V 5 W/21 W × 1 |
| Neutral indicator light | 12 V 1.7 W × 1 |
| Reverse indicator light | 12 V 1.7 W × 1 |



MAINTENANCE SPECIFICATIONS

ENGINE

| Model | YFM350S |
|--|---|
| Rocker arm/rocker arm shaft | |
| Rocker arm inside diameter | 11.980 ~ 11.998 mm (0.4717 ~ 0.4724 in) |
| Rocker arm shaft outside diameter | 11.961 ~ 11.971 mm (0.4709 ~ 0.4713 in) |
| Rocker-arm-to-rocker-arm-shaft clearance | 0.009 ~ 0.037 mm (0.0004 ~ 0.0015 in) |
| Carburetor | |
| I.D. mark | 5YT1 00 |
| Main jet (M.J) | #142.5 |
| Main air jet (M.A.J) | #35 |
| Jet needle (J.N) | 5JFC39-2 |
| Needle jet (N.J) | P-0M |
| Pilot jet (P.J) | #22.5 |
| Pilot air jet (P.A.J.1) | #65 |
| (P.A.J.2) | #165 |
| Pilot outlet (P.O) | 1 |
| Bypass 1 (B.P.1) | 0.8 |
| Bypass 2 (B.P.2) | 0.8 |
| Bypass 3 (B.P.3) | 0.8 |
| Pilot screw turns out (P.S) | 2-1/4 (For CDN, Europe, and Oceania) |
| Valve seat (V.S) | 2.5 |
| Starter jet (G.S) | #70 |
| Throttle valve size (Th.V) | #105 |
| Fuel level (F.L) | 4 ~ 5 mm (0.16 ~ 0.20 in) |
| | Above the float chamber mating surface |
| Float height | 13.0 mm (0.51 in) |
| Engine idling speed | 1,450 ~ 1,550 r/min |
| Intake vacuum | 33.3 kPa (250 mmHg, 9.83 inHg) |

Tightening torques

| Part to be tightened | Part name | Thread size | Q'ty | Tightening torque | | | Remarks |
|--|-----------|-------------|------|-------------------|--------|---------|--------------------|
| | | | | Nm | m · kg | ft · lb | |
| Carburetor joint | Bolt | M8 | 2 | 20 | 2.0 | 14 | Use a lock washer. |
| Carburetor clamp (cylinder head side) | Screw | M4 | 1 | 3 | 0.3 | 2.2 | |
| Carburetor clamp (air filter case side) | Screw | M4 | 1 | 3 | 0.3 | 2.2 | |
| Air filter case | Screw | M4 | 1 | 3 | 0.3 | 2.2 | |
| Muffler and exhaust pipe | Bolt | M8 | 1 | 16 | 1.6 | 11 | |
| Muffler | Bolt | M8 | 2 | 34 | 3.4 | 24 | |
| Clutch cable holder | Bolt | M8 | 1 | 16 | 1.6 | 11 | |
| Right crankcase cover | Bolt | M6 | 15 | 10 | 1.0 | 7.2 | |
| Left crankcase cover | Bolt | M6 | 9 | 11 | 1.1 | 8.0 | |
| Crankshaft end cover | Bolt | M6 | 4 | 7 | 0.7 | 5.1 | |
| Bearing retainer (balancer shaft) | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Bearing retainer (main axle) | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Bearing retainer (left crankcase) | Screw | M5 | 2 | 7 | 0.7 | 5.1 | |
| Drive sprocket | Nut | M20 | 1 | 90 | 9.0 | 65 | |
| Stopper lever | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Reverse shift cam stopper bolt | Bolt | M14 | 1 | 18 | 1.8 | 13 | |
| Drive select lever assembly | Bolt | M8 | 2 | 20 | 2.0 | 14 | |
| Drive select lever shift rod and reverse shift cam | Bolt | M6 | 1 | 16 | 1.6 | 11 | |
| Shift rod (shift pedal) locknut | Nut | M6 | 2 | 8 | 0.8 | 5.8 | |



CHASSIS

| Model | YFM350S |
|-----------------------------------|--|
| Steering system | |
| Lock-to-lock angle | |
| Left | 42.5° |
| Right | 42.5° |
| Front suspension | |
| Shock absorber stroke | 90.0 mm (3.54 in) |
| Shock absorber spring free length | 232.5 mm (9.15 in) |
| Spring rate | (K1) 32.00 N/mm (3.26 kg/mm, 182.72 lb/in) |
| | (K2) 45.00 N/mm (4.59 kg/mm, 256.95 lb/in) |
| Spring stroke | (K1) 0 ~ 45.0 mm (0 ~ 1.77 in) |
| | (K2) 45.0 ~ 90.0 mm (1.77 ~ 3.54 in) |
| Optional spring | No |
| Rear suspension | |
| Shock absorber stroke | 88.0 mm (3.46 in) |
| Shock absorber spring free length | 238.5 mm (9.39 in) |
| Spring rate | (K1) 57.00 N/mm (5.81 kg/mm, 325.46 lb/in) |
| Stroke | 0 ~ 88.0 mm (0 ~ 3.46 in) |
| Enclosed gas pressure | (standard) 1,500 kPa (15.0 kg/cm ² , 213.3 psi) |
| | (Min) 1,450 kPa (14.5 kg/cm ² , 206.2 psi) |
| | (Max) 1,550 kPa (15.5 kg/cm ² , 220.4 psi) |
| Wheel | |
| Front wheel type | Panel wheel |
| Rear wheel type | Panel wheel |
| Front rim size/material | 10 × 5.5 AT/Aluminum |
| Rear rim size/material | 9 × 8.5 AT/Aluminum |
| Rim runout limit | |
| Vertical | <2.0 mm (0.08 in)> |
| Lateral | <2.0 mm (0.08 in)> |
| Front disc brake | |
| Type | Dual disc brake |
| Disc outside diameter × thickness | 161.0 × 3.5 mm (6.34 × 0.14 in) |
| <Limit> | <3.0 mm (0.12 in)> |
| Pad thickness | 4.2 mm (0.17 in) |
| <Limit> | <1.0 mm (0.04 in)> |
| Rear disc brake | |
| Type | Single disc brake |
| Disc outside diameter × thickness | 200.0 × 3.6 mm (7.87 × 0.14 in) |
| <Limit> | <3.1 mm (0.12 in)> |
| Pad thickness | 4.5 mm (0.18 in) |
| <Limit> | <1.0 mm (0.04 in)> |



MAINTENANCE SPECIFICATIONS

SPEC



| Model | YFM350S |
|------------------------------------|--|
| Brake lever and brake pedal | |
| Brake lever free play | 0 mm (0 in) |
| Brake pedal position | 50.2 mm (1.98 in) From the top of the frame to the top of the brake pedal |
| Throttle lever free play | 2 ~ 4 mm (0.08 ~ 0.16 in) |
| Drive chain | |
| Type/manufacturer | DID520V/DAIDO |
| Number of links | 97 + 1 links |
| Chain free play | 25.0 ~ 35.0 mm (0.98 ~ 1.38 in) |

Tightening torques

| Part to be tightened | Thread size | Tightening torque | | | Remarks |
|--|-------------|-------------------|--------|---------|---|
| | | Nm | m · kg | ft · lb | |
| Engine and frame | M10 | 73 | 7.3 | 53 | |
| Front shock absorber and frame | M10 | 48 | 4.8 | 35 | |
| Front shock absorber and lower arm | M10 | 48 | 4.8 | 35 | |
| Steering knuckle and front wheel hub | M14 | 70 | 7.0 | 50 | |
| Steering shaft and frame | M10 | 35 | 3.5 | 25 | |
| Tie-rod locknut | M10 | 15 | 1.5 | 11 | |
| Disc cover (inner) | M6 | 7 | 0.7 | 5.1 | |
| Front brake master cylinder | M6 | 7 | 0.7 | 5.1 | |
| Clutch and parking brake lever assembly | M5 | 4 | 0.4 | 2.9 | |
| Front brake hose and upper front arm | M6 | 7 | 0.7 | 5.1 | |
| Front brake pipe and brake pipe joint | M10 | 19 | 1.9 | 13 | |
| Brake pipe joint and frame | M6 | 10 | 1.0 | 7.2 | |
| Brake caliper bleed screw | M8 | 6 | 0.6 | 4.3 | |
| Rear brake hose union bolt | M10 | 28 | 2.8 | 20 | |
| Parking brake adjusting bolt and locknut | M8 | 16 | 1.6 | 11 | |
| Rear brake light switch bracket and frame | M6 | 7 | 0.7 | 5.1 | |
| Rear brake master cylinder and frame | M8 | 23 | 2.3 | 17 | |
| Rear brake fluid reservoir and frame | M6 | 7 | 0.7 | 5.1 | |
| Rear brake hose and swingarm | M6 | 7 | 0.7 | 5.1 | |
| Rear hub and rear brake caliper | M8 | 34 | 3.4 | 24 | |
| Rear axle ring nut | M33 | 160 | 16.0 | 115 |  |
| Rear axle ring nut set bolt | M6 | 7 | 0.7 | 5.1 |  |
| Rear hub and swingarm (lower) | M10 | 73 | 7.3 | 53 | |
| Rear shock absorber and frame | M12 | 80 | 8.0 | 58 | |
| Relay arm and swingarm | M12 | 73 | 7.3 | 53 | |
| Rear shock absorber and relay arm | M12 | 73 | 7.3 | 53 | |
| Connecting rod and relay arm | M12 | 73 | 7.3 | 53 | |
| Connecting rod and frame | M12 | 73 | 7.3 | 53 | |
| Spring preload adjusting locknut (rear shock absorber) | M44 | 42 | 4.2 | 30 | |

MAINTENANCE SPECIFICATIONS

SPEC



| Part to be tightened | Thread size | Tightening torque | | | Remarks |
|--|-------------|-------------------|--------|---------|---------|
| | | Nm | m · kg | ft · lb | |
| Swingarm guard and swingarm | M8 | 16 | 1.6 | 11 | |
| Driven chain sprocket and boss | M10 | 55 | 5.5 | 40 | |
| Front bumper | M8 | 12 | 1.2 | 8.7 | |
| Rear bumper | M8 | 34 | 3.4 | 24 | |
| Drive chain guard | M8 | 12 | 1.2 | 8.7 | |
| Foot protectors (left and right) and frame | M8 | 16 | 1.6 | 11 | |
| Foot protectors (left and right), rear fender stay and frame | M8 | 17 | 1.7 | 12 | |
| Foot protectors (left and right) and footrest | M8 | 17 | 1.7 | 12 | |
| Footrest and frame | M10 | 73 | 7.3 | 53 | |
| Battery holder | M6 | 10 | 1.0 | 7.2 | |
| Front fender and front fender bracket | M6 | 7 | 0.7 | 5.1 | |
| Front fender and frame | M6 | 7 | 0.7 | 5.1 | |
| Front fender bracket (center) and frame | M6 | 10 | 1.0 | 7.2 | |
| Front fender brackets (left and right) and frame | M6 | 13 | 1.3 | 9.4 | |
| Headlight bracket and front fender bracket | M6 | 7 | 0.7 | 5.1 | |
| Rear fender and frame | M6 | 10 | 1.0 | 7.2 | |
| Rear fender and rear bumper | M6 | 7 | 0.7 | 5.1 | |
| Rear fender and rear fender stay | M6 | 7 | 0.7 | 5.1 | |
| Rear fender stay and frame | M6 | 7 | 0.7 | 5.1 | |
| Rear fender stay and frame | M8 | 16 | 1.6 | 11 | |
| Engine skid plate and frame | M8 | 12 | 1.2 | 8.7 | |
| Fuel tank | M6 | 7 | 0.7 | 5.1 | |
| Fuel cock and fuel tank | M6 | 4 | 0.4 | 2.9 | |
| Rectifier/regulator | M6 | 7 | 0.7 | 5.1 | |
| Tail/brake light bracket and rear fender | M6 | 4 | 0.4 | 2.9 | |




ELECTRICAL

| Model | YFM350S |
|---|--|
| C.D.I. Magneto model/manufacturer Pickup coil resistance (Color) Rotor rotation direction detection coil resistance (Color) C.D.I. unit-model/manufacturer | F4T466/MITSUBISHI 459 ~ 561 Ω at 20 °C (68 °F) (White/Red-White/Green) 0.083 ~ 0.101 Ω at 20 °C (68 °F) (Red-White/Blue) F8T40374/MITSUBISHI |
| Rectifier/regulator Regulator type Model/manufacturer No-load regulated voltage Rectifier capacity Withstand voltage | Semi conductor-short circuit SH640E-11/SHINDENGEN 14.1 ~ 14.9 V 14 A 200 V |
| Starter relay Model/manufacturer Amperage rating Coil winding resistance | 2768095-A/JIDECO 180 A 4.18 ~ 4.62 Ω |
| Battery Specific gravity | 1.310 at 20 °C (68 °F) |
| Starter motor Model/manufacturer Output Armature coil resistance Brush overall length Brush spring pressure Commutator diameter Mica undercut | DBQD5/DENSO 0.7 kW 0.0118 ~ 0.0133 Ω at 20 °C (68 °F) 12 mm (0.47 in) 8.5 mm (0.33 in) 6.38 ~ 9.32 N (651 ~ 950 gf, 22.96 ~ 33.55 oz) 28 mm (1.10 in) 27 mm (1.06 in) 0.6 mm (0.024 in) |



CABLE ROUTING


- ① Clutch switch lead
 - ② Starter cable
 - ③ Clutch cable
 - ④ Parking brake cable
 - ⑤ Front brake hose
 - ⑥ Front brake light switch lead
 - ⑦ Throttle cable
 - ⑧ Neutral indicator light
 - ⑨ Reverse indicator light
 - ⑩ Handlebar switch lead
- [A] Fasten the front brake light switch lead with two plastic bands.
 - [B] Fasten the starter cable, clutch switch lead, and handlebar switch lead with a plastic band.
 - [C] Fasten the clutch switch lead and handlebar switch lead with a plastic band.






- ① Parking brake cable
- ② Clutch cable
- ③ Starter cable
- ④ Clutch switch lead
- ⑤ Handlebar switch lead
- ⑥ Neutral/reverse indicator light lead
- ⑦ Rectifier/regulator
- ⑧ Front brake light switch lead
- ⑨ Front brake hose
- ⑩ Throttle cable

- Ⓐ Pass the clutch switch lead, handlebar switch lead, neutral/reverse indicator light lead, front brake light switch lead, and starter cable through the guide.
- Ⓑ Fasten the clutch switch lead, handlebar switch lead, neutral/reverse indicator light lead, and front brake light switch lead securely with a plastic locking tie.






- ⓐ Route the clutch switch lead, handlebar switch lead, neutral/reverse indicator light lead, and front brake light switch lead in front of the guide.
- ⓓ Pass the throttle cable, clutch cable, and parking brake cable to the right side of the steering shaft.





- ① Rectifier/regulator
- ② Ignition coil
- ③ Wire harness
- ④ Starter cable
- ⑤ Fuel tank breather hose
- ⑥ Fuel hose
- ⑦ Carburetor air vent hose
- ⑧ Crankcase breather hose
- ⑨ Reverse switch lead
- ⑩ Negative battery lead
- ⑪ Carburetor overflow hose
- ⑫ Neutral switch lead
- ⑬ Starter motor lead
- ⑭ Clutch cable
- ⑮ Parking brake cable




CABLE ROUTING

SPEC



- A** Pass the parking brake cable and clutch cable through the cable guide.
- B** Pass the carburetor air vent hose through the hole in the fuel tank.
- C** The end of the carburetor air vent hose should extend at least 15 mm above the hole but not be higher than the intake of the air filter case.
- D** Pass the clutch cable and parking brake cable between the carburetor overflow hose and crankcase breather hose.
- E** Fasten the A.C. magneto lead, neutral switch lead, reverse switch lead, and negative battery lead with a plastic band. Face the end of the plastic band inward.
- F** Pass the neutral switch lead and carburetor overflow hose through the guide on the drive sprocket cover. Route the neutral switch lead behind the carburetor overflow hose.
- G** Fasten the A.C. magneto lead with the holder.




CABLE ROUTING

SPEC



- H** Fasten the parking brake cable and clutch cable with the clip. Fasten the clip to the clutch cable between the cable protector and the clutch cable adjuster.
- I** Pass the parking brake cable and clutch cable through the cable guide.
- J** Fasten the wire harness, starter motor lead, and starter cable with a plastic band. Face the end of the plastic band down.
- K** Pass a plastic band through the hole in the fuel tank shield, and then fasten the wire harness, starter motor lead, and starter cable with the plastic band. The end of the plastic band should be under the frame, facing inward.
- L** Route the wire harness and starter motor lead above the starter cable.
- M** Fasten the wire harness and starter motor lead with a plastic band. Face the end of the plastic band inward.




CABLE ROUTING

SPEC



- ① Tail/brake light lead
- ② Battery
- ③ C.D.I. unit
- ④ Wire harness
- ⑤ Starter motor lead
- ⑥ Negative battery lead
- ⑦ Carburetor air vent hose
- ⑧ Positive battery lead
- ⑨ Starter relay
- ⑩ Starting circuit cut-off relay

- Ⓐ Pass the wire harness, negative battery lead, and starter motor lead through the hole in the rear fender.
- Ⓑ More than 15 mm (0.6 in)



CABLE ROUTING


SPEC



- ① Drive select lever switch
- ② Ground terminal
- ③ Throttle cable
- ④ Drive select lever switch lead
- ⑤ Main switch lead
- ⑥ Headlight lead
- ⑦ Ignition coil
- ⑧ Rectifier/regulator
- ⑨ Starter motor lead
- ⑩ Starter motor
- ⑪ Parking brake cable


- ⑫ Rear brake light switch
- ⑬ Rear brake light switch lead
- ⑭ Drive select lever switch connector

- A** Route the rear brake light switch lead over the parking brake cable.
- B** Pass the parking brake cable through the cable guides.
- C** Fasten the drive select lever switch lead with a plastic band. Face the end of the plastic band inward.





- D** Route the drive select lever switch lead on the outside of the drive select lever bracket, and then under the ground lead.
- E** Fasten the throttle cable and drive select lever switch lead with a plastic clamp.
- F** Route the main switch lead over the headlight bracket.
- G** Pass the headlight lead between the headlight bracket and the headlight.
- H** Route the starter motor lead in front of the front fender bracket.
- I** Pass the starter motor lead through the guide.
- J** Fasten the rear brake light switch lead under the frame with two plastic bands. Face the end of each band rearward.
- K** Pass a plastic band through the holes in the fuel tank shield, and then fasten the throttle cable and drive select lever switch connector with the plastic band. The end of the plastic band should be under the frame, facing inward.




CABLE ROUTING

SPEC



- ① Ignition coil
- ② Headlight lead
- ③ Main switch lead
- ④ Spark plug lead
- ⑤ Drive select lever switch lead
- ⑥ Throttle cable
- ⑦ Starter motor lead
- ⑧ Wire harness
- ⑨ Starter cable
- ⑩ Rectifier/regulator


- A Fasten the wire harness with the holder.
- B Route the headlight lead over the frame.
- C Fasten the main switch lead with the holder on the front fender.
- D Pass the main switch lead through the guide on the front fender.






- ① Starter relay
- ② Positive battery lead
- ③ C.D.I. unit
- ④ Battery
- ⑤ Tail/brake light lead
- ⑥ Negative battery lead
- ⑦ Starting circuit cut-off relay
- ⑧ Wire harness
- ⑨ Starter motor lead

- A Fasten the wire harness by inserting the projections on the plastic tab into the hole in the rear fender.
- B Pass the tail/brake light lead through the guide on the rear fender.
- C Fasten the tail/brake light lead with the holders on the rear fender.
- D Route the tail/brake light lead under the battery holding bracket.





- E Connect the end of the negative battery lead with the gray tape to the negative battery terminal.
- F Cover the positive battery lead terminal and starter motor lead terminal with the covers.





EB300000

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION

| ITEM | ROUTINE | INITIAL | | | EVERY | |
|--|---|--|-----------------------|-----------------------|-----------------------|-----------------------|
| | | 1 month | 3 months | 6 months | 6 months | 1 year |
| Valves* | <ul style="list-style-type: none"> • Check valve clearance. • Adjust if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Spark plug | <ul style="list-style-type: none"> • Check condition. • Adjust gap and clean. • Replace if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Air filter element | <ul style="list-style-type: none"> • Clean. • Replace if necessary. | Every 20 ~ 40 hours (More often in wet or dusty areas.) | | | | |
| Carburetor* | <ul style="list-style-type: none"> • Check starter (choke) operation. • Adjust engine idling speed. | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Crankcase breather system* | <ul style="list-style-type: none"> • Check breather hose for cracks or damage. • Replace if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Exhaust system* | <ul style="list-style-type: none"> • Check for leakage. • Tighten if necessary. • Replace gasket(s) if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Fuel line* | <ul style="list-style-type: none"> • Check fuel hose for cracks or damage. • Replace if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil | <ul style="list-style-type: none"> • Replace. (Warm engine before draining.) | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil filter element | <ul style="list-style-type: none"> • Clean. • Replace if necessary. | <input type="radio"/> | | <input type="radio"/> | | <input type="radio"/> |
| Engine oil strainer | <ul style="list-style-type: none"> • Clean. | <input type="radio"/> | | <input type="radio"/> | | <input type="radio"/> |
| Drive chain | <ul style="list-style-type: none"> • Check and adjust slack/alignment/clean/lube. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Brakes* | <ul style="list-style-type: none"> • Check operation/fluid leakage/See NOTE page 24. • Correct if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Clutch* | <ul style="list-style-type: none"> • Check operation. • Adjust if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheels* | <ul style="list-style-type: none"> • Check balance/damage/runout. • Replace if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheel bearings* | <ul style="list-style-type: none"> • Check bearing assemblies for looseness/damage. • Replace if damaged. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Steering system* | <ul style="list-style-type: none"> • Check operation. • Repair if damaged. • Check toe-in. • Adjust if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Front and rear suspension* | <ul style="list-style-type: none"> • Check operation. • Correct if necessary. | | | <input type="radio"/> | | <input type="radio"/> |
| Upper and lower arm pivot and steering shaft* | <ul style="list-style-type: none"> • Lubricate every 6 months with lithium-soap-based grease. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Rear arm pivot* | <ul style="list-style-type: none"> • Lubricate every 6 months with lithium-soap-based grease. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |

PERIODIC MAINTENANCE/LUBRICATION



| ITEM | ROUTINE | INITIAL | | | EVERY | |
|--------------------------------|--|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| | | 1 month | 3 months | 6 months | 6 months | 1 year |
| Fittings and fasteners* | <ul style="list-style-type: none"> • Check all chassis fittings and fasteners. • Correct if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Lights and switches* | <ul style="list-style-type: none"> • Check operation. • Adjust headlight beams. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

NOTE: _____

- Recommended brake fluid: DOT 4
- Brake fluid replacement:
 - When disassembling the master cylinders or calipers, replace the brake fluid. Normally check the brake fluid level and add fluid as required.
 - On the inner parts of the master cylinders and calipers, replace the oil seals every two years.
 - Replace the brake hoses every four years, or if cracked or damaged.


WARNING _____

Indicates a potential hazard that could result in serious injury or death.

EBS00033

SEAT, FENDERS AND FUEL TANK


SEAT, SIDE COVERS, AND FRONT PANEL



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|---|
| | Removing the seat, side covers, and front panel | | Remove the parts in the order listed. |
| 1 | Seat | 1 | NOTE: _____ Pull back the seat lock lever, than pull up on the rear of the seat. _____ |
| 2 | Left side cover | 1 | |
| 3 | Right side cover | 1 | |
| 4 | Front panel | 1 | |
| | | | For installation, reverse the removal procedure. |

EBS00034


FOOT PROTECTORS, ENGINE SKID PLATE, AND FRONT BUMPER



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the foot protectors, engine skid plate, and front bumper | | Remove the parts in the order listed. |
| 1 | Left foot protector | 1 | |
| 2 | Right foot protector | 1 | |
| 3 | Engine skid plate | 1 | |
| 4 | Front bumper | 1 | |
| | | | For installation, reverse the removal procedure. |

EBS00036


HEADLIGHTS AND FRONT FENDER



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the headlights and front fender | | Remove the parts in the order listed. |
| | Seat/side covers (left and right)/front panel | | Refer to "SEAT, SIDE COVERS, AND FRONT PANEL". |
| 1 | Headlight coupler | 2 | Disconnect. |
| 2 | Left headlight | 1 | |
| 3 | Right headlight | 1 | |
| 4 | Main switch coupler | 1 | Disconnect. |
| 5 | Front fender | 1 | |
| | | | For installation, reverse the removal procedure. |


EBS00039

REAR FENDER



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---|
| | Removing the rear fender | | |
| | Seat/side covers (left and right) | | Remove the parts in the order listed. Refer to "SEAT, SIDE COVERS, AND FRONT PANEL". |
| 1 | Battery lead | 2 | CAUTION: <u>First disconnect the negative lead, then disconnect the positive lead.</u> |
| 2 | Battery holding bracket | 1 | |
| 3 | Battery | 1 | |
| 4 | Crankcase breather hose | 1 | Disconnect. |
| 5 | Clamp screw | 1 | Loosen. |
| 6 | Air filter case | 1 | |
| 7 | Starter relay | 1 | |
| 8 | Starting circuit cut-off relay | 1 | |
| 9 | C.D.I. unit | 1 | |


SEAT, FENDERS AND FUEL TANK




| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------|------|--|
| 10 | Tail/brake light coupler | 1 | Disconnect. |
| 11 | Rear fender | 1 | For installation, reverse the removal procedure. |

EBS00042

FUEL TANK



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---|
| | Removing the fuel tank | | |
| | Seat/side covers (left and right) | | Remove the parts in the order listed. Refer to "SEAT, SIDE COVERS, AND FRONT PANEL". |
| | Front fender | | Refer to "HEADLIGHTS AND FRONT FENDER". |
| 1 | Fuel hose (fuel cock side) | 1 | NOTE: _____ Before disconnecting the fuel hose, turn the fuel cock to "OFF". _____ |
| 2 | Fuel tank | 1 | NOTE: _____ When installing the fuel tank, pass the fuel tank breather hose through the hole in the handlebar cover. _____ |
| 3 | Plastic band | 2 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|--|
| 4 | Fuel tank shield | 1 | For installation, reverse the removal procedure. |

ADJUSTING THE PARKING BRAKE/ ADJUSTING THE REAR SHOCK ABSORBER



- i. Slide the rubber cover to its original position.

⚠ WARNING

After this adjustment is performed, lift the rear wheels off the ground by placing a block under the engine, and spin the rear wheels to ensure there is no brake drag. If any brake drag is noticed perform the above steps again.





EBS00111

ADJUSTING THE REAR SHOCK ABSORBER

1. Remove:
 - seat
Refer to “SEAT, SIDE COVERS, AND FRONT PANEL”.
2. Remove:
 - air filter case
Refer to “REAR FENDER”.
3. Adjust:
 - spring preload




- a. Elevate the rear wheels by placing a suitable stand under the frame.
- b. Loosen the locknut ①.
- c. Turn the adjusting ring ② in direction ③ or ④.



| | |
|--------------------|--|
| Direction ③ | Spring preload is increased (suspension is harder). |
| Direction ④ | Spring preload is decreased (suspension is softer). |

| | |
|------------------------------|--|
| Adjusting length ⑤ | |
| Standard: 228.5 mm (9.00 in) | |
| Minimum: 218.5 mm (8.60 in) | |
| Maximum: 233.5 mm (9.19 in) | |



EBS00120

ELECTRICAL SYSTEM

CHECKING AND CHARGING THE BATTERY

⚠ WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- **DO NOT SMOKE** when charging or handling batteries.
- **KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.**
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin — Wash with water.
- Eyes — Flush with water for 15 minutes and get immediate medical attention.



INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

CAUTION:

- This is a sealed battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
 - Charging time, charging amperage and charging voltage for an MF battery are different from those of conventional batteries. The MF battery should be charged as explained in the charging method illustrations. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.
-

CHECKING AND CHARGING THE BATTERY



6. Charge:

- battery
(refer to the appropriate charging method illustration)


⚠ WARNING

Do not quick charge a battery.


CAUTION:

- Never remove the MF battery sealing caps.
- Do not use a high-rate battery charger since it forces a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the machine. (If charging has to be done with the battery mounted on the machine, disconnect the negative battery lead from the battery terminal.)
- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
- As shown in the following illustration, the open-circuit voltage of an MF battery stabilizes about 30 minutes after charging has been completed. Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.


Charging method using a variable-current (voltage) charger





Charging method using a constant voltage charger



CAUTION: Constant amperage chargers are not suitable for charging MF batteries.





EBS00124

REPLACING A HEADLIGHT BULB

1. Disconnect:
 - headlight lead coupler ①
2. Remove:
 - headlight bulb holder cover ②
3. Remove:
 - bulb holder ①
 - bulb

NOTE: _____

Push the headlight bulb holder inward, turn it counterclockwise and remove the defective bulb.

⚠ WARNING _____

Keep flammable products and your hands away from the bulb while it is on, since it will be hot. Do not touch the bulb until it cools down.

4. Install:
 - bulb **New**


CAUTION: _____

Avoid touching the glass part of the bulb. Keep it free from oil; otherwise, the transparency of the glass, life of the bulb, and luminous flux will be adversely affected. If oil gets on the bulb, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.


5. Install:
 - bulb holder
 - headlight bulb holder cover ①

NOTE: _____

After installing the bulb holder cover, make sure that the “TOP” mark ③ is in the position shown.



6. Connect:
 - headlight lead coupler ②



ENGINE

ENGINE REMOVAL INSTALLING THE ENGINE

⚠ WARNING

Securely support the machine so there is no danger of it falling over.


1. Install:
 - engine assembly
2. Install:
 - engine lower mounting bolt (rear)/nut ①
 - engine upper mounting bolt (rear)/nut ②
 - engine lower mounting bolt (front)/nut ③
 - engine bracket (left and right) ④
 - engine bracket bolts ⑤
 - engine upper mounting bolt (front)/nut ⑥

NOTE:

- All mounting bolts should be installed from the right of the machine.
- Do not fully tighten the bolts and nuts.

3. Tighten:


- engine lower mounting bolt (rear)/nut ①
🔩 73 Nm (7.3 m · kg, 53 ft · lb)
- engine upper mounting bolt (rear)/nut ②
🔩 73 Nm (7.3 m · kg, 53 ft · lb)
- engine lower mounting bolt (front)/nut ③
🔩 73 Nm (7.3 m · kg, 53 ft · lb)
- engine bracket bolts ⑤
🔩 33 Nm (3.3 m · kg, 24 ft · lb)
- engine upper mounting bolt (front)/nut ⑥
🔩 33 Nm (3.3 m · kg, 24 ft · lb)



CLUTCH

INSTALLING THE RIGHT CRANKCASE COVER

1. Install:
 - right crankcase cover

 10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:


When installing the right crankcase cover, push the push lever in direction ① and check that the punch mark ② on the push lever aligns with the mark ③ on the right crankcase cover.




EBS00141

CARBURETOR


CARBURETOR



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------|------|--|
| | Removing the carburetor | | Remove the parts in the order listed. |
| | Fuel tank/air filter case | | Refer to "SEAT, FENDERS AND FUEL TANK". |
| 1 | Plastic band | 1 | |
| 2 | Drive select lever assembly | 1 | |
| 3 | Throttle valve cover | 1 | |
| 4 | Throttle cable | 1 | |
| 5 | Carburetor air vent hose | 1 | Disconnect. |
| 6 | Starter plunger | 1 | |
| 7 | Clamp screw | 1 | Loosen. |
| 8 | Carburetor | 1 | |
| | | | For installation, reverse the removal procedure. |




| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|--------------------------------------|
| | Disassembling the carburetor | | Remove the parts in the order below. |
| ① | Throttle stop screw | 1 | |
| ② | Vacuum chamber cover | 1 | |
| ③ | Piston valve spring | 1 | |
| ④ | Jet needle holder/jet needle set | 1 | |
| ⑤ | Piston valve | 1 | |
| ⑥ | Coasting enricher assembly | 1 | |
| ⑦ | Float chamber | 1 | |
| ⑧ | Float pin | 1 | |
| ⑨ | Float | 1 | |
| ⑩ | Needle valve | 1 | |
| ⑪ | Needle valve seat | 1 | |
| ⑫ | Starter jet | 1 | |
| ⑬ | Pilot jet | 1 | |
| ⑭ | Main jet | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------|------|--|
| ⑮ | Main jet holder | 1 | For assembly, reverse the disassembly procedure. |
| ⑯ | Needle jet | 1 | |
| ⑰ | Pilot air jet | 1 | |
| ⑱ | Pilot screw | 1 | |



CHASSIS

REAR WHEELS AND REAR AXLE HUB





| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the rear wheels and rear axle hub | | Remove the parts in the order listed. |
| 1 | Cotter pin | 2 | Refer to "REAR WHEEL AND WHEEL HUB" in chapter 6. (Manual No.: 3GD-AE5) |
| 2 | Axle nut | 2 | |
| 3 | Rear wheel | 2 | |
| 4 | Wheel hub | 2 | |
| 5 | Bolt | 2 | Refer to "REMOVING THE REAR AXLE" and "INSTALLING THE REAR AXLE". |
| 6 | Nut | 1 | |
| 7 | Locknut | 2 | |
| 8 | Adjusting bolt | 2 | |
| 9 | Brake caliper | 1 | NOTE: Do not apply the brake pedal and do not use the parking brake when the brake caliper is off of the brake disc as the brake pad will be force shut. |

REAR WHEELS AND REAR AXLE HUB



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|-------|--|
| 10 | Brake disc/brake disc bracket | 1/1 | |
| 11 | Rear axle | 1 | Refer to "REMOVING THE REAR AXLE". |
| 12 | Driven sprocket/sprocket bracket | 1/1 | |
| 13 | Rear axle hub | 1 | |
| 14 | Spacer/bearing/oil seal | 1/2/2 | For installation, reverse the removal procedure. |




EBS00393

REMOVING THE REAR AXLE

1. Place the machine on a level surface.
2. Remove:
 - bolts ①
3. Loosen:
 - nut ②


NOTE:

- Apply the parking brake so that the rear axle does not turn, when loosening the nut.
- Use the axle nut wrench (46 mm) ③.




Axle nut wrench (46 mm)
P/N. 90890-01498/YM-37134

4. Elevate the rear wheels by placing the suitable stand under the frame.
5. Remove:
 - rear wheels
 - wheel hubs
 - nut



6. Loosen:
 - rear axle hub nuts ①




7. Loosen:
 - locknut ①
 - adjusting bolt ②

NOTE:


Loosen the locknut and adjusting bolt on each side of the machine.

FRONT ARMS AND FRONT SHOCK ABSORBER





EBS00468

FRONT ARMS AND FRONT SHOCK ABSORBER




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the front arms and front shock absorber | | Remove the parts in the order listed. The following procedure applies to both of the front arms and front shock absorbers. |
| | Muffler/exhaust pipe | | Refer to "ENGINE ASSEMBLY AND ADJUSTMENT" in chapter 4. (Manual No.: 3GD-AE5) |
| | Front wheel/brake disc/front brake caliper | | Refer to "FRONT WHEEL AND WHEEL HUB" in chapter 6. (Manual No.: 3GD-AE5) |
| | Front bumper | | Refer to "SEAT, FENDERS AND FUEL TANK". |
| 1 | Tie-rod | 1 | Disconnect. |
| 2 | Front shock absorber | 1 | |

FRONT ARMS AND FRONT SHOCK ABSORBER



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|---|
| 3 | Upper front arm | 1 | Refer to "FRONT SUSPENSION—REMOVAL" in chapter 6. (Manual No.: 3GD-AE5) |
| 4 | Lower front arm | 1 | |
| 5 | Steering knuckle | 1 | |
| 6 | Dust cover | 8 | |
| 7 | Spacer | 4 | |
| 8 | Bushing | 8 | |
| | | | For installation, reverse the removal procedure. |



REAR BRAKE

ASSEMBLING THE REAR BRAKE CALIPER


1. Install:

- parking brake arm ①

NOTE:

Install the parking brake arm so that the parking-brake-arm-to-parking-brake-bracket distance ① is approximately 73 mm (2.87 in).


REAR SHOCK ABSORBER AND SWINGARM



| Order | Job/Part | Q'ty | Remarks |
|-------|--|-------|---|
| | Removing the rear shock absorber and swingarm | | Remove the parts in the order listed. |
| | Rear wheel/rear axle hub | | Refer to "REAR WHEELS AND REAR AXLE HUB". |
| | Parking brake cable/rear brake hose | | Refer to "REAR SHOCK ABSORBER AND SWINGARM" in chapter 6. (Manual No.: 3GD-AE5) |
| | Drive chain | | Refer to "DRIVE CHAIN AND SPROCKETS" in chapter 6. (Manual No.: 3GD-AE5) |
| 1 | Swingarm skid plate | 1 | |
| 2 | Rear shock absorber | 1 | |
| 3 | Spacer | 2 | |
| 4 | Spacer | 1 | |
| 5 | Relay arm | 1 | |
| 6 | Dust cover/bushing/spacer | 2/2/1 | |

REAR SHOCK ABSORBER AND SWINGARM

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------|-------|--|
| 7 | Connecting rod | 1 | |
| 8 | Oil seal/bushing/spacer | 4/4/2 | |
| 9 | Drive chain guide | 1 | |
| 10 | Pivot shaft/washer/nut | 1/1/1 | |
| 11 | Swingarm | 1 | |
| 12 | Dust cover/washer/oil seal | 2/2/2 | |
| 13 | Drive chain protector | 1 | |
| 14 | Bearing/spacer | 2/1 | |
| | | | For installation, reverse the removal procedure. |


EBS00485

HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER

⚠ WARNING

This rear shock absorber and gas cylinder contain highly compressed nitrogen gas. Before handling the rear shock absorber or gas cylinder, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber and gas cylinder.

- Do not tamper or attempt to open the rear shock absorber or gas cylinder.
- Do not subject the rear shock absorber or gas cylinder to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber or gas cylinder in any way. If the rear shock absorber, gas cylinder or both are damaged, damping performance will suffer.



DISPOSING OF THE REAR SHOCK ABSORBER AND GAS CYLINDER

Gas pressure must be released before disposing of the rear shock absorber and gas cylinder. To release the gas pressure, drill a 2 ~ 3-mm hole through the gas cylinder at a point ① 50 mm (1.97 in) from its end as shown.


⚠ WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.

ELECTRICAL

ELECTRICAL COMPONENTS


- ① Rectifier/regulator
- ② Main switch
- ③ Neutral indicator light
- ④ Reverse indicator light
- ⑤ Ignition coil
- ⑥ Drive select lever switch
- ⑦ Battery
- ⑧ C.D.I. unit
- ⑨ Starting circuit cut-off relay
- ⑩ Fuse
- ⑪ Starter relay
- ⑫ Reverse switch
- ⑬ Neutral switch
- ⑭ Rear brake light switch
- ⑮ Wire harness





YAMAHA MOTOR CO., LTD.
2500 SHINGAI IWATA SHIZUOKA JAPAN

YFM350S WIRING DIAGRAM



- ① A.C. magneto
- ② Rectifier/regulator
- ③ Main switch
- ④ Battery
- ⑤ Fuse
- ⑥ Starter relay
- ⑦ Starter motor
- ⑧ Clutch switch
- ⑨ C.D.I. unit
- ⑩ Ignition coil
- ⑪ Spark plug
- ⑫ Starting circuit cut-off relay
- ⑬ Drive select lever switch
- ⑭ Neutral switch
- ⑮ Indicator light assembly
- ⑯ Neutral indicator light
- ⑰ Reverse indicator light
- ⑱ Reverse switch
- ⑲ Rear brake light switch
- ⑳ Front brake light switch
- ㉑ Tail/brake light
- ㉒ Headlight
- ㉓ Handlebar switch
- ㉔ Light switch
- ㉕ Engine stop switch
- ㉖ Start switch

COLOR CODE

- | | | | | | | | |
|----------|--------|-----------|--------------|-----------|-------------|-----------|------------|
| B | Black | Sb | Sky blue | L/B | Blue/Black | W/L | White/Blue |
| Br | Brown | W | White | L/W | Blue/White | W/R | White/Red |
| G | Green | Y | Yellow | R/B | Red/Black | | |
| L | Blue | B/Y | Black/Yellow | R/W | Red/White | | |
| O | Orange | G/L | Green/Blue | W/B | White/Black | | |
| R | Red | G/W | Green/White | W/G | White/Green | | |